## operating instructions SIGA® - Safety Wrench

## "ATTENTION: Read the instructions carefully before use and keep them in a safe place for future reference."

SIGA® - Safety Wrench are tools for opening and closing of immovable and Fittings with handwheels.

To open or close the fitting, hook the fork inot the handwheel as shown in the photos and turn clockwise (to close) or anticlockwise (to open).

You must always check the condition of the wrench before using it.

## 1. <u>Open</u>







Marking of the SIGA®-Wrench:

and extension protection

Colour marking red; with rubber handle

as Model B, with colour marking brass,

Colour marking bronze and stamp D

Model A: Colour marking red

and stamp C

Model B:

Model C:

Model D:

To find out which key size is suitable for which valve handwheels, please see of the following table:

Size	DN/mm	ca. lenght / mm A	ca. lenght / mm B/C/D	weight ca. in gr.
00	10-50	260	300	200
0	25–80	270	310	360
1	50-100	330	370	600
2	125 - 250	440	480	1000
3	250-400	560	590	1600
4	350-900	765	800	2150

The SIGA® - Assortment for all handwheels for fittings

## 1. The SIGA®-Wrenches may not be extended by inserting in pipes !!!

- 2. The SIGA®-Wrenches may only be operated with gloves on.
- 3. Do not leave the handwheel wrench unattended during use.
- 4. For version "C", the Technical Information Safety Note must be observed

For technical questions we are always at your disposal.

